## **Describing hydrogen diffusion in ceramic** thin films materials

P. Rückeshäuser<sup>1</sup>, A. Bahr<sup>1</sup>, W. Zhao<sup>1</sup>, R. Hahn<sup>1</sup>, O. Hudak<sup>1</sup>, T. Wojcik<sup>1</sup>, S. Kolozsvári<sup>2</sup>, P. Polcik<sup>2</sup>, T. Stelzig<sup>3</sup>, F. Rovere<sup>3</sup>, H. Riedl<sup>1,4\*</sup>

<sup>1</sup>Christian Doppler Laboratory for Surface Engineering of high-performance Components, TU Wien, Austria <sup>2</sup> Plansee Composite Materials GmbH, D-86983 Lechbruck am See, Germany Oerlikon Balzers, Oerlikon Surface Solutions AG, 9496 Balzers, Liechtenstein Institute of Materials Science and Technology, TU Wien, A-1060 Wien, Austria



•	thin film crystal lattice
	Substrate

- Within this study, the electrochemical Devanathan-Stachursky setup is tested to describe the hydrogen permeation within CrN and TiN coatings grown by different deposition techniques

<sup>1</sup>V. Nemanic, Hydrogen permeation barriers: Basic requirements, materials selection, deposition methods, and quality evaluation, Nuclear Materials and Energy, 2019 <sup>2</sup> J. Matějíček et al.: Characterization of less common nitrides as potential permeation barriers, Fusion Engineering and Design, 2019

## <u>Methodology</u>

SETU

MEASUREMENT

ALS

MATERI

COATING

• The cell the coated sample

\*corresponding author: <u>helmut.riedl@tuwien.ac.at</u>

- On the entry side hydrogen is produced galvanostatically by the decomposition of water
- Hydrogen gets adsorbed and atomically permeates through the sample towards the exit side to oxidize
- Generated electrons create a current that can be measured



• Variation of coating thickness results in slight influence on diffusion coefficients of sputtered and arced TiN and CrN coatings

NIEN

- Different morphologies affect hydrogen diffusivity
- Results for 1.0330 steel substrates in good comparison to literature



Coating thickness (µm)

- CAE, Oerlikon Balzers Innova
- Magnetron Sputtering, Lab scaled

• Porosity was evaluated via linear sweep voltammetry (LSV) for arced TiN • There is a clear correlation between decreasing coating porostiy and increasing PRF

- Electrochemical hydrogen permeation testing is a relatively young and upcoming method concerning hydrogen permeability evaluation of PVD coatings. • It serves as an **alternative** to the differential pressure method.
- It is highly sensitive and has **direct measures** for hydrogen transportation
- There is a **difference** in hydrogen barrier properties between **arced and sputtered** coatings of comparable thicknesses, that needs to be investigated further
- LSV experiments suggest, that porosities act as pathways for hydrogen diffusion and higher coating density significantly **hinders hydrogen** permeation

œrlikon balzers

PLANSEE

The financial support by the Austrian Federal Ministry for Digital and Economic Affairs and the National Foundation for Research, Technology and Development is gratefully acknowledged (Christian Doppler Laboratory "Surface Engineering of high-performance Components"). We also thank for the financial support of Plansee SE, Plansee Composite Materials GmbH, and Oerlikon Balzers, Oerlikon Surface Solutions AG.

Christian Doppler Forschungsgesellschaft